

Exit Phase (Before Drogue Fall)

Bag out immediately on exit

Deploy drogue, release drogue immediately and expect malfunction – (If cannot deploy drogue) disconnect RSL, cut-away and deploy reserve

Unstable on exit

Try to physically rectify student's position to gain stability, if unsuccessful deploy drogue preferably in a face to earth position

Side spin

If left side down, deploy drogue, if right side down initiate reserve deployment. It may still be advantageous to deploy drogue even if right side down

Drogue release handle pulled prior to deployment of drogue

Immediately deploy drogue

Unable to locate drogue

Check drogue has not prematurely deployed, if not immediately initiate reserve deployment

Unable to deploy drogue

Immediately initiate reserve deployment

Drogue Fall

Drogue does not inflate

Pull drogue release handle after 6-8 seconds

Drogue detaches / breaks

Immediately initiate reserve deployment

Cannot locate (Or Pull) drogue release handle

Pull secondary drogue release handle

Cannot locate (Or Pull) secondary drogue release handle

Pull third drogue release / cutaway handle and initiate reserve deployment, but expect main cutaway and RSL reserve deployment

Drogue bridle becomes entangled

Have one attempt to clear, if unsuccessful initiate reserve deployment

Main container opens during drogue fall

Pull drogue release handle, be prepared for a malfunction

Either arm incapacitated by injury or by student

Pull primary or secondary drogue release handle (you have one on each side)

Unable to locate either primary or secondary drogue release handles

Pull third drogue release / cutaway handle and initiate reserve deployment, but expect main cutaway and RSL reserve deployment

Primary Drogue Release Handle Pulled

Main Malfunctions

Cut-away and initiate reserve deployment

Drogue pilot chute detaches on primary drogue release pull

If main does not deploy pull second drogue release and third drogue release / cutaway handle and initiate reserve deployment. Disconnect RSL as soon as possible.

Inflated drogue does not release

Pull secondary drogue release handle

Inflated drogue in tow

Pull third drogue release / cutaway handle and initiate reserve deployment, Disconnect RSL as soon as possible