

---

## TANDEM INSTRUCTOR EQUIPMENT CONVERSION REQUIREMENTS

The following guidelines will assist British Skydiving Tandem Examiners in the required procedure for carrying out a Tandem System Conversion.

A Tandem conversion course may be delivered by an Independent Tandem Examiner at any Affiliated Parachute Training Organisation (PTO) under the following conditions.

1. The conversion course must be authorised by the STO or the COO.
2. The Independent Tandem Examiner must be trained and current on the Tandem System for conversion.

A full familiarisation of the Tandem System must take place as part of the conversion process covering the following requirements:

1. Familiarisation of new Tandem System differences and be familiar with the manufacturers manual.
2. Carry out a packing assessment.
3. Must be fully proficient in the suspended harness drills and practiced the drills with the British Skydiving 'B' Licence skydiver on the front before they are allowed to carry out any Tandem descents on the new Tandem System.
4. All conversion descents must be filmed, and footage sent to British Skydiving HQ.

The jump requirements for full conversion are as per the British Skydiving Operations Manual Section 4, (Instructors), Para 5.5, (Tandem System Conversion).

1. At least 1 jump with a suitable container.
2. A minimum of 2 descents with a British Skydiving 'B' Licence skydiver or above acting as a Student Tandem Skydiver.

*N.B. The requirements for those acting as Student Tandem Skydivers can be found in Section 4, Para 5.5.2 of the British Skydiving Operations Manual.*

## TANDEM INSTRUCTOR EQUIPMENT CONVERSION TABLE

CONTAINER TYPE	CONFIGURATION	MAIN DEPLOYMENT LOCATION	CONVERT TO	CONFIGURATION	MAIN DEPLOYMENT LOCATION	REMARKS
<b>VECTOR 2 TANDEM</b>						
Vector	Vector	Left BOC	Atom Galaxy	Galaxy	Left BOC	No Conversion Required
Vector	Vector	Left BOC	Next	Next	Left BOC	No Conversion Required
Vector	Vector	Left BOC	Sigma	Sigma	Left BOC	No Conversion Required
<b>Vector</b>	<b>Vector</b>	<b>Left BOC</b>	<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Full Conversion Required</b>
Vector	Vector	Left BOC	Strong	Vector	Left BOC	No Conversion Required
Vector	Vector	Left BOC	Strong	Next	Left BOC	No Conversion Required
<b>Paratec Next</b>						
Next	Next	Left BOC	Atom Galaxy	Galaxy	Left BOC	No Conversion Required
Next	Next	Left BOC	Sigma	Sigma	Left BOC	No Conversion Required
<b>Next</b>	<b>Next</b>	<b>Left BOC</b>	<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Full Conversion Required</b>
Next	Next	Left BOC	Strong	Vector	Left BOC	No Conversion Required
Next	Next	Left BOC	Strong	Next	Left BOC	No Conversion Required
Next	Next	Left BOC	Vector	Vector	Left BOC	No Conversion Required
<b>PDF Atom Galaxy</b>						
Atom Galaxy	Galaxy	Left BOC	Next	Next	Left BOC	No Conversion Required
Atom Galaxy	Galaxy	Left BOC	Sigma	Sigma	Left BOC	No Conversion Required
<b>Atom Galaxy</b>	<b>Galaxy</b>	<b>Left BOC</b>	<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Full Conversion Required</b>
Atom Galaxy	Galaxy	Left BOC	Strong	Vector	Left BOC	No Conversion Required
Atom Galaxy	Galaxy	Left BOC	Strong	Next	Left BOC	No Conversion Required
Atom Galaxy	Galaxy	Left BOC	Vector	Vector	Left BOC	No Conversion Required
<b>UPT Sigma / UPT Micro Sigma</b>						
Sigma	Sigma	Left BOC	Next	Next	Left BOC	No Conversion Required
Sigma	Sigma	Left BOC	Atom Galaxy	Galaxy	Left BOC	No Conversion Required
<b>Sigma</b>	<b>Sigma</b>	<b>Left BOC</b>	<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Full Conversion Required</b>
Sigma	Sigma	Left BOC	Strong	Vector	Left BOC	No Conversion Required
Sigma	Sigma	Left BOC	Strong	Next	Left BOC	No Conversion Required
Sigma	Sigma	Left BOC	Vector	Vector	Left BOC	No Conversion Required
<b>Strong Enterprises Dual Hawk / Hawk</b>						
<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Next</b>	<b>Next</b>	<b>Left BOC</b>	<b>Full Conversion Required</b>
<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Atom Galaxy</b>	<b>Galaxy</b>	<b>Left BOC</b>	<b>Full Conversion Required</b>
<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Sigma</b>	<b>Sigma</b>	<b>Left BOC</b>	<b>Full Conversion Required</b>
<b>Strong</b>	<b>Strong</b>	<b>Right Lift Web</b>	<b>Vector</b>	<b>Vector</b>	<b>Left BOC</b>	<b>Full Conversion Required</b>
Strong	Next	Left BOC	Next	Next	Left BOC	No Conversion Required
Strong	Vector	Left BOC	Vector	Vector	Left BOC	No Conversion Required
Strong	Next	Left BOC	Vector	Vector	Left BOC	No Conversion Required
Strong	Vector	Left BOC	Next	Next	Left BOC	No Conversion Required
Strong	Strong	Left BOC	Atom Galaxy	Galaxy	Left BOC	No Conversion Required
Strong	Strong	Left BOC	Atom Galaxy	Galaxy	Left BOC	No Conversion Required
Strong	Strong	Left BOC	Sigma	Sigma	Left BOC	No Conversion Required
Strong	Strong	Left BOC	Sigma	Sigma	Left BOC	No Conversion Required

**For any Tandem Systems where no conversion jumps are required, the Tandem Instructor must have practiced and be proficient with the emergency drills in the suspended harnesses for the new Tandem System prior to making any Tandem descents.**